

# GIGA X8c

## Descaling the machine

Approximate duration 45 min.


Equipment required:  
 Descaling tablets  
 Box containing 36 pcs (Art. 70751)




These short instructions do not replace the »GIGA X8c Instructions for Use«. Make sure you read and observe the safety information and warnings first in order to avoid hazards.

»Display«




Precondition: 'Decalcify machine'






'Descale'



'Empty drip tray'




'Pour descaling agent into water tank'




'Press the Rotary Switch'




'Machine is being descaled'  
 'Empty drip tray'



'Fill water tank'






'Press the Rotary Switch'



'Machine is being descaled'  
'Empty drip tray'



'Descal' / 'Descaling  
complete.'